

Sony HDW-F900 Shutter Angle Equivalents (when shooting 24/23.98p)

F900 Shutter Angle Selections

Shutter Off

Shutter 1/32

Shutter 1/48

Shutter 1/50

Shutter 1/60

Shutter 1/96

Shutter 1/125

Shutter 1/250

Shutter 1/500

Shutter 1/1000

ECS

Shutter Angle Degrees Equivalents

No shutter selected

Movement within the frame will blur

270° Shutter

180° Shutter

172.8° Shutter

144° Shutter

90° Shutter

69.12° Shutter

34.56° Shutter

17.28° Shutter

8.64° Shutter

Electronic Clean Scan

Dial in shutter frequency to eliminate roll bars or flickering from monitors, fluorescent bulbs, etc. 24.00Hz – 2200Hz



Information provided by AMV / Cine Services
(212) 727-1234
www.allmobilevideo.com